

● Blind and screen information


Features:

This specially designed panel has three functions:


1. The blind prevents light entry and provides privacy.
2. Screen delivers protection from bugs.
3. It can act as emergency exit, when the screen and blind are unlocked and window open.

Instructions:

Use the central handle, to pull or push the blind downwards or upwards to any position. (Diagram 7)



The blind and screen can be locked together by joining at middle catch. Once locked together, they can be positioned as required. (Diagram 8)



To unlock, press down on the catch in the handle. (Diagram 9)

